


Machine control : exciter EXST2 pu



Machine control : exciter EXST2 pu.....	1
1 Description	1
1.1 Pins.....	1
1.2 Parameters	1
1.3 Input.....	2
1.4 Output.....	2
1.5 Representation	2

1 Description

This device is an implementation of an IEEE Type ST2 excitation system similar to PSS/E's EXST2 exciter model. This version of the exciter interprets all input and output values as per-unit quantities. For a version with input and output in physical units, use the device "exciter EXST2".

1.1 Pins

This device has seven pins:

<i>pin</i>	<i>type</i>	<i>description</i>	<i>units</i>
Efd_ic	input pin	initial field voltage at t=0	pu(Efd_base)
Vmeas_rms	input pin	measured rms voltage	pu(V_base)
Vaux	input pin	auxiliary voltage order	pu(V_base)
Vterm	2-signal bundle	terminal voltage magnitude	pu(V_base)
		terminal voltage angle	rad
Iterm	2-signal bundle	terminal current magnitude	pu(I_base)
		terminal current angle	rad
Ifd	input pin	field current	pu(Ifd_base)
Efd	output pin	field voltage	pu(Efd_base)

1.2 Parameters

The value of the following parameters must be defined:

parameter	description	units
Tr	time constant (lag) of voltage meter	s
Ta	time constant (lag) of regulator	s
Te	time constant (lag) of exciter	s
Tf	time constant (lag) of feedback	s
Ka	gain of regulator	
Ke	gain of exciter	
Kf	gain of feedback	
Vrmin	regulator low limit	pu(Efd_base)
Vrmax	regulator high limit	pu(Efd_base)
Efd_max	exciter high limit	pu(Efd_base)
Kp	rectifier gain on terminal voltage	
Ki	rectifier gain on terminal current	
Kc	rectifier gain on field current	

1.3 Input

The input pins may be connected to any control signals. The input phasors may be connected to any phasor bundles.

The following inputs are available:

input	description	units
Efd_ic	initial field voltage at t=0	pu(Efd_base)
Vmeas_rms	measured rms voltage	pu(V_base)
Vaux	auxiliary voltage order	pu(V_base)
Vterm	terminal voltage magnitude	pu(V_base)
	terminal voltage angle	rad
Iterm	terminal current magnitude	pu(I_base)
	terminal current angle	rad
Ifd	field current	pu(Ifd_base)

1.4 Output


The output value is the calculated field voltage, in per-unit of the base field voltage.

output	description	units
Efd	field voltage	pu(Efd_base)

1.5 Representation

The implementation of the model can be inspected by opening the device's subcircuit. The model is self-initializing at t=0.

The dynamic representation of the model is the following:



where

$$V_{in} = V_{ref} - V_{meas_rms} + V_{aux} \quad (1)$$

with V_{meas_rms} filtered by $\frac{1}{1+sT_r}$

and with the value of V_{ref} calculated to produce $E_{fd} = E_{fd_ic}$ at $t=0$.

The internal signals are:

signal	description	units
Vin	control input	pu(V_base)
Ve	control error	pu(V_base)
Vu	regulator voltage	pu(Efd_base)
Vb	rectifier correction	pu(Efd_base)
Vra	regulator adjusted voltage	pu(Efd_base)
Vf	feedback	pu(V_base)